


Notes:

1. Mechanically prepare concrete surfaces in accordance with ICRI 03732 to achieve a concrete surface profile of CSP-3 or higher, or in accordance with manufacturer's requirements.
2. Remove existing joint sealant and backing materials, and mechanically prepare joint wall substrates per the sealant manufacturer's recommendations.
3. Expansion joint must be a minimum of ¼" X ¼".
4. Polyurethane joint sealant must be twice the width as the depth up to ½".
5. Tool flush and sprinkle oven dried sand immediately into sealant surface while tacky. Allow to cure minimum 24 hrs, recommended 48 hrs, or as required.
6. Apply detail coat of Miracote Poly Fabric embedded into Miraflex Membrane C, per manufacturer's installation guidelines, over expansion and control joints. Miraflex Membrane C detail coat(s) shall extend 4" minimum on each side of joint.
7. Install Miracote Miraflex Membrane C in accordance with specifications and the manufacturer's installation guidelines.



- Concrete surface preparation** - - - - -
 - Concrete surface preparation of CSP-3 or higher
- #30 Oven dry sand** —————
- Miraflex Membrane C** —————
- 10" Poly Fabric embedded into Miraflex Membrane C** —————

MIR-MEMC-EJ1

1/12/14

NTS

EXPANSION JOINT DETAIL
Miraflex Membrane C

