


**Notes:**

1. Mechanically prepare concrete surfaces in accordance with ICRI 03732 to achieve a concrete surface profile of CSP-3 or higher, or per manufacturer's requirements.
2. Install cant bead of polyurethane sealant at vertical transition, per sealant manufacturer's recommendations. Tool flush/sprinkle oven dried sand immediately into sealant surface while tacky. Allow to cure minimum 24 hrs, 48 hrs recommended, or as required.
3. Install Miracote Miraflex Membrane C in accordance with specifications and manufacturer's installation guidelines.



- Concrete surface preparation** - - - - -
  - Concrete surface preparation of CSP-3 or higher
- #30 Oven dry sand** —————
- Miraflex Membrane C** —————
- 10" Poly Fabric embedded into Miraflex Membrane C** —————

MIR-MEMC-CPD1

1/12/14

NTS

CHANGE IN PLANE DETAIL  
Miraflex Membrane C

