



## Installation Guideline

## MiraGard NanoGlass White or Pigmented Exposed Pebble Finish Plaster

Step #	Installation Step	Installation Methods	Products & Mix Ratios	Theoretical Coverage Rates
<b>Application Direct to New Exposed Pebble Finishes</b>				
1	<b>Preparation of Pebble Finish</b>  <b>Note:</b> Thoroughly rinse entire pool finish to finish to remove neutralizing residues and debris.	a. Install pebble finish plaster per manufacturer's current instructions. b. Utilize preferred exposure method. c. Neutralize plaster finish.	<b>MiraGard NanoGlass</b> must be applied to a clean and dry pebble plaster finish free of any surface debris, sand and/or other contaminants.	N/A
2a	<b>Apply MiraGard NanoGlass 1st Application</b>  <b>Note:</b> Apply the NanoGlass onto plaster evenly to refusal until a light wet sheen appears on the plaster surface. Avoid over-application and puddling. Immediately remove NanoGlass from non-plaster surfaces while still wet.	a. Pump Sprayer (low pressure) (low pressure pump with fan tip) b. Backroll immediately c. Brush - as needed to detail d. Soft cloth - as needed to wipe down all non-plaster surfaces. e. Sponges - to absorb any areas of puddling material.	<b>MiraGard NanoGlass</b> Single component  <b>Note:</b> Refer to the Product Technical Data Sheet (PTDS) for MiraGard NanoGlass prior to application of this material.	250 - 350 SF/GAL  <b>*Actual rate of consumption is dependent on several factors including plaster mix design, and degree of porosity. Always install a mock-up sample to verify.</b>
2b	<b>Apply MiraGard NanoGlass 2nd Application - Repeat as above</b>  <b>Note:</b> Once sheen from the 1st application has faded, re-apply NanoGlass in opposite direction.	<b>Same as above</b>	<b>MiraGard NanoGlass</b> Single component	<b>Same as Above</b>
3	<b>Cure times for Filling of Pool</b>	a. Monitor Rates of Evaporation	Temperature, relative humidity and wind velocity will determine when to fill. <b>Refer to guide below.</b>	

Temperatures (°F) - Do not apply @ <45°F	Cure Time	Relative Humidity (Baseline 55%)
45°F - 60°F	6 - 10 Hours	<b>Consult PCA Rate of Evaporation Chart and Adjust Cure Time as Needed</b>
60°F - 80°F	2 - 4 Hours	
80°F - 95°F	1 Hour	
<b>Do Not Apply if Substrate is &gt;95°F</b>		

**Note:** Prior to starting the application of any Miracote Product or System be sure to read the most current Installation Guide(s), Product Data Sheets, SDS and other pertinent documents published by Crossfield Product Corp. for information, including but not limited to, Precautions, Limitations, Disclaimers and Warranties. Pay special attention to substrate moisture content, physical condition of the substrate, method(s) of surface preparation, and any applicable specifications. Review carefully for unknown site conditions or defects.

The theoretical coverage rates stated in the Installation Guides are for estimating purposes only. Factors, such as, allowance for material waste, unusual or abnormal substrate conditions and other unforeseen job site conditions that may affect actual product yields are the responsibility of the installer.

