


**Notes:**

1. Mechanically prepare cracks >1/16" width, per manufacturer's requirements.
2. Mechanically prepare concrete surfaces in accordance with ICRI Guideline No. 310.2R-2013 to achieve a concrete surface profile of CSP-3 or higher, or per manufacturer's requirements.
3. Seal routed cracks with CPC Hybrid Sealant. Tool flush and sprinkle oven dried sand immediately into sealant surface while wet. \*\*Sand may be omitted if Membrane C is applied directly to CPC Hybrid Sealant while it is wet.\*\*
4. Apply detail coat of Miracote Poly Fabric embedded into Miraflex Membrane C, per manufacturer's installation guidelines, over cracks <1/16", cold joints and all routed cracks previously sealed with CPC Hybrid Sealant. Miraflex Membrane C detail coat(s) shall extend 4" minimum on each side of crack.
5. Install Miracote Miraflex Membrane C in accordance with specifications and the manufacturer's installation guidelines.



- Concrete surface preparation** █
- Concrete surface preparation of CSP-3 or higher
- #30 Oven dry sand** █
- Miraflex Membrane C** █
- 10" Poly Fabric embedded into Miraflex Membrane C** █

MIR-MEMC-CT1		CRACK TREATMENT DETAIL Miraflex Membrane C	 Division of Crossfield Products Corp.
4/12/20	NTS		